MODEL WSP-i250

(2inch Industrial Printer)

Rev. 1.0



WOOSIM SYSTEMS Inc. #501, Daerung Technotown 3th, 448, Gasan-Dong, GeumChun-Ku, Seoul, Korea Tel : +82-2-2107-3700 Fax : +82-2-2107-3707 URL: http://www.woosim.com

All specifications are subjected to change without notice

http://www.woosim.com

(T)Nanu \mathcal{O}

Copyright

WSP-i250 2inch Industrial printer operator's manual. Copyright ©2014 by Woosim Systems Inc. All rights reserved.

The information contained in this manual is the property of Woosim Systems Inc. And may not be reproduced in whole or in part without the prior written permission of Woosim Systems Inc.

Trademark

All other trademark are the properties of their respective companies.



Some semiconductor devices are easily damaged by static electricity. You should turn the printer "OFF", before you connect or removed the cable on the rear side, in order to guard the printer against the static electricity.

If the printer is damaged by the static electricity, you should turn the printer "OFF"



The contents of this manual are subject to change without notice.

Introduction

The **WSP-i250** is the ideal solution for Mobile banking system , Retail, point of sales, Credit card Transaction, other traveling and mobile computing etc.

The general features of WSP-i250 printer are as follows:

- Compact size (92.12×140.56×59.75mm)
- Light weight (406.5g) for true mobility [standard]
- Very silent printing thru direct thermal printing method
- High speed (120mm/sec, MAX)
- High resolution(203dpi : 8dots/mm).
- UART(RS-232C or TTL), Bluetooth Ver2.1 + EDR, USB[option] Wireless LAN (IEEE802.11b/g)[option] interface
- Support Graphic LCD(128×32dots) with Blue LED Backlight
- Support Magnetic Stripe Reader [option]
- Support Smart Card Module [option]
- Support text and graphic printing
- Intutive LED's indicate Power(on/off), Error
- Easier paper roll loading by CLAMSHELL design
- One touch paper cover
- Printer door open & Paper-out sensor
- Easier maintenance with self-diagnostic.
- In field programming Update Firmware, Download Fonts and Logos
- ▶ Water-resistant construction.(IP54 Certified)
- Microsoft Windows XP/VISTA/7-32bit/7-64bit/CE/Linux/Android compatible.
- Flow control : Software (XON/XOFF)
 - $\ensuremath{\mathbb{X}}$ Hardware flow control not supported in printer.
- Free fall: 2M drop resistance
- Agency Approvals



Operating Precautions

Please follow the precautions below to enjoy and maintain the full performance of the printer.

Using the Printer

- Be careful not to drop or bump the printer on a hard surface.
- Do not install the printer in direct sunlight or such areas.
 - Suitable environment for the use of the printer is as follows:
 - ♦ Operating temperature :-10°C to 50°C
 - ◆ Relative humidity : 30% to 80%
- Do not install the printer near devices that generate strong electromagnetic fields such as a copy machine.
- Do not open the platen cover during printing .
- Do not remove or reinstall the communication cable during printing or transmission.
- Do not touch the connectors of the communication during printing.
- Switch the POWER OFF when not in use.
- Do not use other solvent.
- The AC adapter, the battery charger and the battery pack may become warm when in use. This is normal and is not a malfunction.
- When the battery pack is used at low temperature, the length of time the printer can be used may be shortened.

Thermal Paper Handling

- Store the thermal paper in a cool, dry and dark place.
- Do not rub the paper with hard object.
- Do not leave the paper with hard object.
- Do not allow plastic film, erasers, or adhesive tape to touch the paper for long periods.
- Do not stack the thermal paper with diazo copies immediately after copying or wet-type copies.
- Do not use chemical glue.
- Always use the clean thermal paper.

CONTENTS

1. Outline
1.1. Model classifications
1.2 Product Part Number System7
1.3. Specifications
2. Setting up the printer10
2.1. Printer & Accessories
2.2. Printer Features
2.3. Dimensions
2.4. Replacing paper roll14
2.5. Power supply15
2.5.1. Specified power supply15
2.5.2. Installing the SAM Card and the battery15
2.5.3. Recharging the battery pack16
2.6. Set operation mode17
2.6.1. GAP/HOLE SENSOR SETTING19
2.7. Confirmation of the Wireless-LAN information
2.7.1. MAC Address printing
2.7.2. Confirmation of the Wireless-LAN setting information
3. Interface23
3.1. UART(RS-232C or TTL) or USB
3.2. Bluetooth
3.3. Wireless LAN
3.4. Card Reading & Smart Card insert25
4. Smart Card Module
4.1. General Spec
4.2. Communication Protocol Sequence27
4.2.1. Regular Operation27
4.2.2. Irregular Operation (Communication Error)27
5. Using the printer

5.1. Control panel.	
5.2. The self test	29
5.3. Using the Accessory	29
5.3.1. Using the Shoulder strap	29
5.3.2. Using the Belt clip	30
6. Consumable Parts	31
6.1. Recommended paper	31
6.2. Printing position	31
7. Revision History	32

1. Outline.

1.1. Model classifications.



1.2 Product Part Number System



1.3. Specifications.

Item	Specifications		
Print method	Direct thermal line printing		
Characters per line	42cpl (MAX)		
Character size	Eng: 9*24dots, 12*24dots Kor: 16*24dots, [24*24dots]		
Ontional Characters	Simplified/Traditional Chinese, Arabic, Cyrillic, Russian,		
Optional Characters	Tukish, Greek, Japanese, Persian, Latin9 and Others upon request.		
Resolution	203dpi, 8dots/mm		
Print width	2-inch (48mm, 384dots)		
Print speed	120mm / sec (MAX)		
Dimension	92.12 x 140.56 x 59.75mm		
	92.12 x 144.47 x 59.75mm (MSR Model)		
Weight	406.5a / 413.5a (MSR Model)		
(Including battery)			
Interface	UART(RS-232C or TTL), Bluetooth Ver 2.1 + EDR,		
	USB[option], Wireless LAN interface(IEEE802.11b/g) [option]		
Paper roll	Thermal roll paper (58mm wide, 50ø)		
	1-dimension : Code128, Code39, I2/5, Code93 UPC, EAN, KAN, JAN,		
Parcedos	CODABAR, GS1 Databar		
Barcodes	2-dimension : PDF417, QR Code, DATA Matrix, Micro PDF417,		
	Truncated PDF417, Maxicode		
Driver	Microsoft Widows XP / VISTA / 7-32bit / 7-64bit		
Driver	Windows CE, Linux, Android OS driver compatible		
Black mark	Support black mark detection		
H/W Spec	MCU : Renesas 32Bit, FLASH : 8M bytes, RAM : 16M bytes		
Receive buffer size	1M bytes		
MSR [option]	ISO 7810 / 7811 / 7812 Triple tracks(1&2&3) Reading		

(Continue...)

Item	Specifications			
Smart Card Module	ISO 7816 Compliant	ISO 7816 Compliant (EMV level 1 Certified) /		
[option]	T=0, T=1 support / 1 SAM (Security Application Module)			
LCD	128×32 Dots FSTN (Blue LED Backlight)			
Battery	Rechargeable 7.4V DC, 1400mAh/1800mAh/2200mAh (Li-ion)			
Battery duration	1 hour continuous printing			
Pottom, chownow	Input (100~250V AC, 50~60Hz)			
Battery charger	Output(8.4VDC/0.8A), 4hours full charge time		
	Temperature	-10°C ~ 50°C (operating)		
Environment		-10°C ~ 70°C (storage)		
conditions	Humidity	30% - 80% (operating)		
	Humidity	10% - 90% (storage)		
MCBF(Mean Cycle	Mechanical	37,000,000 lines		
Between Failure)	Head	Approximately 50 Km		

< Table 1 >

2. Setting up the printer.

2.1. Printer & Accessories

Your printer box should include these items. If any items are damaged or missing, please contact your dealer for assistance.



2.2. Printer Features

Part Name



2.3. Dimensions

Standard Model









MSR Model









2.4. Replacing paper roll.

Note : Be sure to use paper rolls that meet the specifications.
Do not use paper rolls that have the paper glued to the core because the printer can not detect the paper end correctly.

- 1. Make sure that the printer is not receiving data; otherwise, data may be lost.
- Open the paper cover as the "One-Touch" way by pressing the button in the arrow direction like the picture.

3. Insert a new paper roll as shown.





4. Tear the excess paper off using the edge of paper door as a tear bar.



2.5. Power supply

2.5.1. Specified power supply

The following specification is requested for Power supply.

Battery Charger : DC 8.4V/0.8A

Avoid using power supply which its power capacity of power current is extremely high.

2.5.2. Installing the SAM Card and the battery

NOTE : Before installing or removing the battery pack, ensure the printer is OFF.
 If the printer is not used for long period of time, remove the

 If the printer is not used for long period of time, remove the battery pack from the printer.

1) To install SAM card, proceed as follows:

-Insert the SAM card in the direction of the arrow.



② To install Battery Pack, proceed as follows:-Insert the Battery Pack in the direction of the arrow.



2.5.3. Recharging the battery pack

For recharging the battery pack, install the battery pack in the printer. Insert the Battery Charger to the charge connector of the printer.





2.6. Set operation mode

In keeping on pressing the Feed and Power button simultaneously until after the ERROR lamp blinks 5 times, the printer comes out at the circumstance to change the printer mode. (refer Table 2)

** Only the printer which support iOS Bluetooth interface comes out at the circumstance to change the printer mode. (Bluetooth Mode or Boluetooth(iAP) Mode).

** Manipulation methods :

- 1 Press Feed and Power buttons simultaneously until the ERROR lamp blinks 5 times and then keep pressing two buttons for 2 Seconds.
- 2 After the printer beeps twice, the Bluetooth mode is changed and it will print the result of change.
- 3. The changed mode can be checked in the printout.

Example) If the printer is in Bluetooth Mode

- \rightarrow Bluetooth(iAP) Mode
- If the printer is in Bluetooth(iAP) Mode \rightarrow Bluetooth Mode

** If you want to change the Bluetooth Mode of printer, you need to disconnect the Bluetooth function of the current paired Smartphone.

- ** Methods :
 - 1. Turn off the Bluetooth function of the current paired Smartphone.
 - (Bluetooth ICON in LCD is disappeared.)
 - 2. Change the printer mode.

(Additionally, we want to recommend you to rest(OFF \rightarrow ON) the printer and change mode.)

Printer LCD status	Android status	iOS status
Bluetoeth Mode	Ideal 19-55 e.A.K Workleve Area manufacture extraining Airplane model durate an extraction extraining Airplane model Airplane A	advace 30 FM (0 10x15) (and 10 M) Bluetooth (077)

- FEED button : changing Printer MODE status.
- **POWER button** : changing OPTION status.

[Example] The defaults of the printer are :

UART / 9600 bps / 8 data bit / No parity /1 stop bit / Density low / Quality low / Mark use / Sensor High / Power down 5 minute

If a user wants to modify the defaults with

Bluetooth / 57,600 bps / 7 data bit / Odd parity /2 stop bit / Density high / Quality high/ Mark Gap/Hole / Sensor Low / Power down no use

- > Press MODE & POWER Button during the Error Lamp flickers 5 times.
 - \rightarrow You will see present **COMMUNICATION** mode in the LCD. (UART)
 - → Press the **POWER Button** twice. And then, interface mode has set to **Bluetooth** mode.
- When you press **FEED button** once.
 - → You will see present **BAUD RATE** mode in the LCD. (9600 bps)
 - → Press **POWER Button** 3 times. And then, **BAUD RATE** has set to **57,600 bps**.
- When you press **FEED button** once.
 - \rightarrow You will see present **DATA BIT** mode in the LCD. (8 Data bit)
 - \rightarrow Press **POWER Button** once. And then Data Bit has set to **7 DATA BIT**.
- When you press **FEED button** once.
 - \rightarrow You will see present **PARITY** mode in the LCD. (No parity)
 - → Press **POWER Button** once. And then the Parity bit has set to **ODD Parity Bit.**
- When you press FEED button once.
- \rightarrow You will see present **STOP BIT** mode in the LCD. (1 stop bit)
- \rightarrow Press **POWER Button** once. And then the density has set to **2 Stop bit**.
- When you press **FEED button** once.
 - → You will see present **DENSITY** mode in the LCD. (Density low)
 - → Press **POWER Button** twice. And then the density has set to **Density high**.

When you press FEED button once.

 \rightarrow You will see present **Quality** mode in the LCD. (Low)

 \rightarrow Press **POWER Button** once. And then the quality has set to **Quality high**.

When you press **FEED button** once.

 \rightarrow You will see present **MARK** mode in the LCD. (Use)

→ Press **POWER Button** once. And then the mark has set to **Mark Gap/Hole**.

When you press FEED button once.

 \rightarrow You will see present **SENSOR** mode in the LCD. (High)

- → Press **POWER Button** once. And then the sensor has set to **Sensor Low**.
- When you press **FEED button** once.
 - → You will see present **POWER DOWN** mode in the LCD. (5 minutes)

→ Press POWER Button once. And then the Power down has set to Power down no use.

If all the mode have set, press the **POWER Button** and the **FEED Button** at the same time. After then release the buttons at the same time.

Bluetooth : 57600bps : 7 data bit : Odd parity : 2 stop bit : Density high : High : Gap/Hole : Low : No use

2.6.1. GAP/HOLE SENSOR SETTING

- 1. Set Mark as GAP / HOLE on mode setting.
- 2. If feed button keeps being pressed during self "SENSOR SETTING" appears on LCD window and paper keeps coming out "SENSOR SETTING".
- 3. If feed button is not pressed after printing more than 3 pages of label
- 4. Setting is completed as Green and Red LED flash and "COMPLETE" appears on LCD window.
- ** Caution : Sensor setting stops if the feed button is not pressed during self test.

MODE	OPTION		
MODE	Bluetooth	WLAN	
	UART(RS-232C)	UART(RS-232C)	
	Protocol UART	Protocol UART	
Communication	(RS-232C)	(RS-232C)	
Port	Bluetooth	WLAN	
	Protocol Bluetooth	Protocol WLAN	
	Bluetooth(iAP)	-	
	9600	bps	
	19200	bps	
Baud Rate	38400	bps	
	57600	bps	
	115200 bps		
Data Bit	7 Data bit		
	8 Data bit		
	No Pa	arity	
Parity Bit	Odd F	Parity	
	Even Parity		
Stop Bit	1 Stop bit		
этор вн	2 Stop bit		
	Density Low		
Density	Density N	/ledium	
	Density High		
Quality	Lo	W	
Quality	Hig	Jh	
	Νοι	Jse	
Mark	Use		
	Gap / Hole		

Continue...

MODE	OPTION
	Low
Sancar	Medium1
Sensor	Medium2
	High
	No use
	1 minute
Bower Down	2 minute
Power Down	3 minute
	4 minute
	5 minute

< Table 2 >

Notice : Bluetooth(iAP) is the mode which is used in iPod, iPhone and iPad Whole aspect.

2.7. Confirmation of the Wireless-LAN information

2.7.1. MAC Address printing

MAC address which is set to the printer can be printed out in pressing the Power and Feed button simultaneously and taking off them shortly after the ERROR lamp blinks

2.7.2. Confirmation of the Wireless-LAN setting information

- Press the Power button in the printer turning on As the Power lamp turns on, MAC Address is indicated.
- ▶ IP Address on LCD is indicated in pressing the Power button once again
- Subnet mask on LCD is indicated in pressing the Power button once again
- ▶ Gateway IP on LCD is indicated in pressing the Power button once again
- > DNS sever IP on LCD is indicated in pressing the Power button once again

※ Since the configuration of Wireless LAN can not be done with the printer in person, you are required to use the Wireless LAN-setting program which WOOSIM offers

3. Interface

3.1. UART(RS-232C or TTL) or USB



The WSP-i250 printer has a UART(RS-232C or TTL) or USB interface and is connected by means of a 5 pin mini USB socket. In the following table, the signals present on the Mini- USB socket are listed:

1 UART(RS-232C or TTL)

Pin No.	Name	Direction	Function
1	TxD	Output	Transmit Data
2	RxD	Input	Receive Data
3	CTS	-	-
4	NC.	-	-
5	GND	-	Ground

② USB

Pin No.	Name	Function
1	VCC	+5V
2	DM	DATA "-"
3	DP	DATA "+"
4	NC.	-
5	GND	Ground

NOTE :

When data receiving, when it removes the Communication cable, it loses a data.

3.2. Bluetooth

Category	Specification
Bluetooth Spec.	Bluetooth Ver2.1 + EDR / Class2 (10m)
Frequency Range	2.4GHz ISM BAND
Data Transmission Rate	57600bps Fixed.
Data bit	8 Data bit Fixed.
Parity bit	No parity Fixed.
Stop bit	1 Stop bit Fixed.

3.3. Wireless LAN

Category	Specification	
Interface	Network IEEE802.11b/g	
Protocol	TCP, UDP, IP, ICMP, ARP, DHCP, PPPoE	
	DNS lookup, DDNS(Dynamic DNS), WEP	
	T2S	TCP Server Mode
	COD	TCP Client Mode
Communication Mode	ATC	TCP Server / Client
		(AT command emulation)
	U2S	UDP

3.4. Card Reading & Smart Card insert

Insert the Smart Card into slot with micro chip facing down.



Please take notice that Magnetic Stripe Card should be swapped in direction of arrow. Card can be read in both

4. Smart Card Module

4.1. General Spec.

- Contact Smart Card Reader Module for ISO/IEC-7816
- Support Asynchronous Protocol T=0,T=1
- Smart Card Connection
 - Short Circuit Current Limitation
 - 6KV ESD Protection on whole Smart Card Interface
 - Connector : Friction Type with Smart Card presence detection
- ▶ 1 SAM (Security Application Module)
- EMV Level 1 Certified

4.2. Communication Protocol Sequence

4.2.1. Regular Operation



4.2.2. Irregular Operation (Communication Error)



5. Using the printer

5.1. Control panel.



BUTTON

- **FEED Button :** When the printer is on, paper can be feed manually by pressing and holding the FEED button for more than one second.

- POWER Button:

- ① When of 5 or more seconds presses and power comes to on or off.
- ② After pressing the POWER and the FEED button simultaneously, if the ERROR lamp 5 turn signals POWER button is converted with MODE functions.

- In keeping on pressing the **Feed and Power button** simultaneously until after the **ERROR lamp** blinks 5 times, the printer comes out at the circumstance to change the printer mode. (Refer to **2.6. Set operation mode** for details about mode conversion)

LAMP

- POWER lamp(GREEN) : Printer is ON and ready to receive data.
- ERROR lamp(RED) : Indicated a fault condition or a printer error.

(i.e : no paper, paper cover opened. etc.)

►LCD

- LCD will display most of the printer status.

(i.e : current printer status, paper out, indicated remaining battery, Bluetooth connection etc.)

5.2. The self test

Self-Test prints out the current setting value of printer. The way of self-test is as follows.

- 1. Insert proper paper into the printer.
- 2. Power on while pressing feed button to start self-test.
- 3. Printer will print out the current status. (ROM version and communication mode)
- 4. And then pattern of characters will be printed out.
- 5. Self-test will be finished automatically and turned to the standby status.

X In case printer does not work properly, please contact Woosim customer service center.

5.3. Using the Accessory

5.3.1. Using the Shoulder strap



Please sling it over your shoulder after fixing the shoulder strap to the printer in the order of the illustration.



5.3.2. Using the Belt clip



Following the instruction of the arrow, please put the belt clip in the hole and turn and fix the screw to the right by using a thing like a coin. Afterward, you can use it like the picture below.



6. Consumable Parts.

6.1. Recommended paper.

Туре	: Thermal Paper
Paper width	: 58mm
Paper thickness	:60±5µm
Outer diameter	: Ø50mm or less
Recording side	: Outside of roll



Cautions

- 1. Do not paste the paper to the core. And the roll paper which has Near end mark printing on its near end is recommended.
- 2. Chemicals or oil may change the color of paper, or printed Characters may fade.

Change of paper color starts from approx 70 ℃.
 Pay attention to heat, humidity and sun light.

4. Color of paper may be changed by being scratched by nail or hard metal, etc

6.2. Printing position.



7. Revision History

Date	Version	Comments
Jul. 25. 2014	1.0	Initialize